


CABLE MODEM or ROUTER with DHCP

IP address:
10.100.100.1

DHCP sends:

- Your address is 10.100.100.2
- Subnet Mask is 255.255.255.0
- Router address is 10.100.100.1
- DNS addresses are 198.60.22.2 and 198.60.22.22



Internet Access Sharing
with WOOWEB-PRO

Configuration with a
router that provides a
DHCP (cable modem
for example)

**Ethernet HUB
or SWITCH
or coax**

